## **BOMBARDIER COMMERCIAL AIRCRAFT**

13100 HENRI-FABRE BLVD MIRABEL, QUÉBEC CANADA J7N 3C6 TEL. 514-855-8500 FAX. 514-855-8501 thd.crj@aero.bombardier.com www.bombardier.com



## REFERENCE INSTRUCTION LETTER

TO:	FROM:	CONTROL NO:	REVISION:	
All Operators	ISE Structures	RIL #6027	NC	
ATTN:	ORIGINATOR:	<b>PAGE</b> : 1 of 2		
N/A	Johanne Forcier			
PHONE NO:	PHONE NO:	A/C MODEL:	A/C S/N:	
N/A	514-855-8500	CL600-2B19 (CRJ200)	ALL	
		CL600-2C10 (CRJ700)		
		CL600-2D15 (CRJ705)		
		CL600-2D24 (CRJ900)		
		CL600-2E25 (CRJ1000	)	
FAX NO:	FAX NO:	ATA NO:		
N/A	514-855-8501	1221		
DATE OF REQUEST:	PUBLICATION AFFE	PUBLICATION AFFECTED:		
7 September 2018	AMM			
TITLE: External Air	raraft Claaning			

TITLE: External Aircraft - Cleaning

**REFERENCE:** /A/ AMM Task 12-21-00-110-801 (All programs)

/B/ Boeing D6-17487 Rev. P /C/ SMI Report REF: 790529

/D/ AMS 1650

/E/ EMB AMM Task 12-22-01

**ISSUE:** In the past, many operators requested from Bombardier a dry wash procedure to

perform external cleaning of aircraft. Actual AMM task for external cleaning allows

only cleaning using wet wash process.

## **RESOLUTION:**

This RIL provides a dry wash procedure (rinseless) to remove light and heavy dirt from external surface of CRJ aircraft.

## Materials:

NuPower II - Nuvite Chemical

Warning: Do not use this dry cleaning procedure to clean aircraft windows/windshields

Note: Always follow the instructions/recommendations from the manufacturer for the

application of the dry wash compound and the cleaning procedure.

Note: Do not perform dry wash cleaning outside if it rains. Use a covered area.

Note: Follow instructions of AMM Task 12-21-00-110-801 for aircraft preparation prior external

cleaning.

RIL # 6027 Page 1 of 2

Procedure:
------------

- 1. Apply equally a moderate layer of NuPower II as is by hand with a white terry cloth towel, cotton flannel cloth or with an applicator pad/mop to small areas at a time.
- 2. Let it fully dry.
  - a. <u>Note</u>: Wait no more than 5-10 minutes for removal after application, even in the highest humidity conditions.
- 3. Wipe the surface with a clean white terry cloth towel, cotton flannel cloth or with a clean mophead to remove the compound and reveal shine. A clean bonnet head on random orbital can also be used.

PREPARED BY:		APPROVAL:	
Print name:	Johanne Forcier	Print name:	Johanne Forcier
Signature:		Signature:	
Date:	7 September 2018	Date:	7 September 2018

This document can be used as acceptable supplementary data for disposition of subject resolution until such time it is cancelled. The current status of the released Reference Instruction Letters is published on the Commercial Aircraft Customer Services – Customer Portal (<a href="http://www.iflybombardier.com/">http://www.iflybombardier.com/</a>)

RIL # 6027 Page 2 of 2