



Warning:

After cleaning pads do not spin dry the BuffPro Heavy Cutting Wool Pad, Polishing Wool Pad, Compounding Wool Pad, or the SLW Wool Pad in the BuffPro Buffer. Doing so may cause severe damage to the pad and void its warranty.

BuffPro Wool Pad Cleaning

Clean BuffPro Pads by hand using a mild detergent, ie. Dawn Dishwashing liquid, and warm water. Work the detergent into the wool portion of the pad using your fingers. Try to keep as much water as possible out of the foam section of the pad. Rinse wool thoroughly with warm water. Squeeze out as much water as possible by hand. Set pad on it's end at room temperature or higher and let dry completely overnight. Pads should be ready for use the following day. **Do Not** spin dry Wool style BuffPro Pads using the BuffPro Buffer.

Manufactures of:

