



Pbs De-Ice Boot System.

Pbs Prep is specifically formulated to clean and strip aircraft de-ice boots from dulling and hard to remove build-up. Prep effectively cleans de-icers of all old boot treatment assuring the best results possible when applying Pbs Boot Sealant.

TIPS: Rubber gloves recommended. If possible, avoid Prep from coming into contact with painted surfaces. Boots can be taped and pulled up on edges. Boots can be stripped faster while wet washing aircraft than stripping by hand.

- Formulated for use before each Pbs Boot Sealant application.
- Will effectively clean de-ice boots of all old boot treatments.
- Failure to prepare de-ice boots with Pbs Prep may result in dulling due to build-up.
- Recommended to use Pbs Prep at least once per quarter to strip and refurbish de-icers and apply fresh coats of Pbs Boot Sealant.

Application Procedure

Set up: To begin the Pbs de-ice boot system application process, you must first have all the proper items available for the job. As you can see in the photo on the left, you will need a pair of latex gloves, a bucket of water, scrubbing sponge, rinsing sponge, microfiber applicator, Pbs Boot Sealant and Pbs Prep. With products and accessories in hand, you are now ready for prepping and sealing your de-ice boots.



Step 1: Cleaning Boots

Put on latex gloves. Apply the Pbs Prep directly to the scrubbing sponge as shown in photo. Using the soft side of the sponge, apply the Pbs Prep to the de-ice boot. By keeping the de-ice boots wet with Pbs Prep for 2 to 3 minutes, all old boot treatments will begin dissolving. At this point, use the scrubbing side of sponge to help re-move old boot treatments. De-ice boot should now be ready for rinsing.



Step 2: Rinsing Boots.

Rinse sponge in clean water as shown in photo on left. Thoroughly re-move all old, dissolved boot treatments. During this process, you will notice excessive amounts of black oxidation coming from surface of boot, this is normal. After drying de-ice boot, it should be flat black in colour and free of all old treatments. Note: If de-ice boot is not free of all old treatments, you will need to repeat step one. When completely free of all old treatments, boot will be ready to be treated with Pbs Boot Sealant.



Step 3: Applying Pbs Boot Sealant.

Apply Pbs Boot Sealant directly on a clean microfiber applicator. Using the treated microfiber applicator apply the Pbs Boot Sealant to de-ice boot in one direction. Apply 3 to 5 coats allowing each coat to dry before applying the next coat. When the de-ice boot is completed, it will have a wet glossy appearance, but will be dry to the touch.



Jet Stream Aviation Products Pbs Boot
Prep and Boot Sealant are available from:

www.frasersaerospace.com